

# INSTRUCTIONS FOR INSTALLATION



INSTALL - Figure 1



INSTALL - Figure 2



INSTALL - Figure 3



INSTALL - Figure 4



INSTALL - Figure 5



INSTALL - Figure 6



Properly Installed  
CarGo Apron

## STEP 1

Place the CarGo Apron in the cargo area behind the front seats and unfold toward the rear of the vehicle (Figure 1).

## STEP 2

Unfold the box end and place the box end cord over the front seat headrests (Figure 2). Use the sliding cord lock to take up any slack in the cord (Figure 5).

## STEP 3

Unfold one side of the CarGo Apron, and hook the front side cord over the garment hook (Figure 3). If there is no garment hook, attach the provided accessory hook and suspend from the grab handle. If there is neither a garment hook or grab handle, attach the suction cup to the door window, about half way up the glass (Figure 4).

## STEP 4

Go to the rear of the vehicle and attach the suction cup to the rear side window about half way up the glass (Figure 4). Use the sliding cord lock to take up any slack in the cord (Figure 5).

Repeat steps #3 and #4 on the opposite side of the vehicle.

After loading, use rear hooks to secure rear flap in the up position (Figure 6).

# INSTRUCTIONS FOR REMOVAL

## STEP 1

Remove the cord from side garment hooks (or alternate attachment). Release suction cups by pulling on small tabs, and place in center of cargo area. Remove cord from headrests.

## STEP 2

Fold flap into cargo area. Fold box end first so that the side panels fold on top (Figure 7). Fold in thirds.

## STEP 3

Roll up from rear of vehicle and secure with cord loop and sliding cord lock (Figure 8).



REMOVAL - Figure 7



REMOVAL - Figure 8